CLAYMOR3 TACE



사용설명서


크레모아 3페이스 미니

본 제품은 리튬폴리머 충전지를 내장한 휴대용 조명기구 제품입니다.

제품을 사용하기 전에 취급 설명서를 반드시 읽고 잘 보관하여 주십시오. 제품에 이상이 확인되는 경우 사용을 중지해 주시고 구입하신 판매점 또는 A/S센터(1588-2303)로 연락해 주시기 바랍니다.


- ① 화기 또는 난방기구 등 고온 주변에서는 사용을 금하여 주십시오. 폭발 및 발화의 원인이 될 수 있습니다. ② 본 제품은 생활방수가 가능합니다. 단, 장시간 빗속에 방치하시면 고장의 원인이 될 수 있습니다. 실수로 물에 빠트렸다면 빠르게 건져서 잘 닦아 주시기 바랍니다.
- ③ 직사광선에 노출된 차량 안에서 보관 및 사용하지 말아 주십시오. 폭발 및 고장의 원인이 될 수 있습니다. ④ 사용 중에는 본체가 매우 뜨거워질 수 있으므로 광원부를 직접 만지지 마십시오.
- ⑤ 사용 온도(- 10° C~ 40° C)의 범위를 넘는 조건에서는 사용을 금하여 주십시오.
- ⑥ LED 광원을 직접 쳐다 보지 마십시오.
- ③ 영유아의 손이 닿는 곳에 두지 말아 주십시오. 부품을 삼키거나 상해를 입는 원인이 될 수 있습니다.
- ⑧ 어린이가 사용하는 경우 보호자의 감시가 필요합니다. 상해 또는 감전의 원인이 될 수 있습니다.
- ③ 접점부나 커넥터의 단자부는 금속류를 절대로 꽂으면 안됩니다. 발열, 폭발, 감전의 원인이 됩니다.
- ⑩ 분해나 개조는 절대로 금합니다.
- ⑪ 젖은 손으로 커넥터 부분을 만지면 안됩니다. 감전의 위험이 있습니다.
- ② 사용 후에는 반드시 전원을 끄고 보관하여 주십시오. 누액의 원인이 될 수 있습니다.
- ⑬ 각도 조절시 무리하게 꺾지 말아 주십시오. 제품 손상의 원인이 될 수 있습니다.
- ® 제품 본체가 낙하 또는 충격을 받으면 제품 내부에 손상이 축적되어 통상적인 사용에도 예상치 못한 고장이 발생할 수있습니다. 본체에 충격이 가해지지 않도록 주의하여 주십시오.

2. 각 부의 명칭




3. 제품 조작 방법


● LED 랜턴 기능




🖒 전원버튼을 짧게 한번 누르면 불이 켜집니다. 다시 짧게 한번 누르면 꺼집니다.



전원 ON 상태에서 🕚 버튼을 계속 누르고 있으면 점점 밝아지고, 다시 계속 누르고 있으면 점점 어두워 집니다. ※최대/최소 밝기시 한번 깜박입니다.



전원 ON 상태에서 ② 버튼을 두번 누르면 오른쪽 그림과 같이 3면 또는 중앙빛을 선택하여 ON/OFF가 가능합니다.



전원 ON 상태에서 ② 버튼을 짧게 누르면 전구색>주백색>주광색 순서로 3단계 빛 색상조절이 가능합니다.

LED 빛색상	특징
전구색(Warm)	색온도가 낮은 전구색, 일반 가스랜턴 처럼 따스한 느낌의 LED 불빛
주백색(Bright)	주광색과 전구색의 중간색으로 화사하며 편안한 느낌의 LED 불빛
주광색(Cool)	색온도가 높은 주광색, 일반 형광등 처럼 시원한 느낌의 LED 불빛



전원 OFF상태에서 🖒 버튼을 2초간 길게 누르면 LED발광부가 SOS신호로 점멸합니다.

● 파워뱅크 기능 (외부 USB기기 충전)



고무 커버를 열고 우측의 포트에 제공된 충전케이블 또는 USB 기기 (스마트폰, 태블릿 PC 등)에서 제공하는 충전케이블을 연결하면 자동으로 충전이 시작됩니다. (On 상태: 배터리 잔량표시등이 켜짐)

⚠ 제품 충전과 동시에 파워뱅크 사용이 안됩니다.

● 제품의 충전



1) 고무 커버를 열고 좌측의 포트에 USB C타입 충전케이블을 연결하면 충전이 시작됩니다.

2) 제품 충전시에는 배터리 잔량표시등이 깜박입니다. 표시등이 깜박이지 않고 켜진 상태가 유지되면 충전이 완료되었음을 나타냅니다.

배터리 잔량 표시등	충전량	
	0~25% 25~50% 50~75% 75~99%	깜빡임
1111	100% 완충시	멈춤

- ※ 메모리 기능이 있어 전원 OFF 후 다시 켤 경우 이전 사용한 빛의 밝기와 모드로 켜지게 됩니다.
- ※ 완전 방전 시 충전 케이블을 꽂을 경우, LED 조명부가 순간 번쩍입니다. 이는 정상적인 현상이므로 불량이 아닙니다.

4. 제품 설치 방법

스트랩과 카라비너를 사용하여 설치 가능합니다.

카라비너 사용시 반드시 스트랩 하단부 홀에 끼워 사용하시기 바랍니다. (비상시 제품 낙하방지



※ 카메라 삼각대에 고정하는 경우 : 카메라 삼각대의 고정나사를 소켓에 돌려 1/4인치 나사를 이용한 제품에 연결하여 다양하게 사용이 가능합니다.

5. 제품 사양

제품명	크레모아 3페이스 미니
모델명	CLF-500(LG/DG/MG)
LED 색온도	전구색(Warm): 3,000K (±15%) 주백색(Bright): 4,200K (±15%) 주광색(Cool) : 6,500K (±15%)
밝기(루멘)	40~800 Lm
사용시간	6시간 30분 ~60시간
사이즈	78×102.5×19.7mm
제품 중량	159g
배터리 타입/용량	Li-Polymer 3.7V 5,000mAh(18,50Wh)
충전 시간	2시간 40분
INPUT(충전 및 전원)	USB 5V 2A
OUTPUT(외부기기 충전)	5V 2A
전기용품 안전인증번호 (배터리) 전자파적합성평가등록번호 (랜턴)	XU100782-17004(모델명:DTP105075) R-R-Prs-CLF-500TN
제조국	MADE IN KOREA

이 기기는 가정용(B급) 전자파적합기기로서 주로 가정에서 사용하는것을 목적으로 하며, 모든 지역에서 사용할 수 있습니다.

6. 구성품









⑤ 매뉴얼

② 카라비너 (USB Type-C) ⚠ 제품 장기 보관시 유의사항

- * 완전히 방전된 후 충전시 잔량표시등이 깜빡이지 않을 수 있습니다. 그럴 경우 USB 케이블을 다시 꽂거나 버튼을 누르면 잔량 표시등이 다시 작동합니다.
- * 장시간 보관시 100% 충전하여 보관하세요
- * 영하10도 이하에서 보관하시면 배터리 수명에 영향이 있을 수 있으니 주의 바랍니다.
- * 습기가 없는 건조한 곳에서 보관하여 주시기 바랍니다.

품질 보증서

제품명	크레모아 3페이스 미니
모델명	CLF-500(LG/DG/MG)
구입처	
구입 일자	

- 1. (주)프리즘의 크레모아 제품을 구입해 주셔서 대단히 감사합니다.
- 2. 본 제품은 엄격한 품질 관리와 시험을 거쳐 출하되었습니다.
- 제품 사용 중 이상이 있을 시에는 하기와 같이 A/S 서비스를 받으실 수 있습니다.

- 1) 품질보증 기간 내에 정상적인 사용으로 발생한 기능상의 하자에 대해서는
- 무상으로 수리해 드리거나 수리가 불가할 경우 새 제품으로 교환해 드립니다.
- 2) 품질 보증기간: 1년 / 부품 보유기간: 3년

유상 서비스

- 1) 품질보증 기간이 경과한 후 발생한 성능 불량 및 고장
- 2) 소비자의 고의 및 과실로 인하여 발생한 고장
- 3) 당사의 서비스 센터가 아닌 곳에서 수리 또는 개조하여 발생한 불량
- 4) 사용 전원의 이상이나 접속기기의 불량으로 인한 고장
- 5) 천재지변에 의한 제품의 결함 또는 불량

PL보험(생산물 배상 책임 보험) 10억원 가입

본 제품은 기획재정부 소비자 피해보상 기준에 의거 교환 또는 보상 받으실 수 있습니다. * 제품의 외관, 사양 등은 제품개발을 위해 사전예고 없이 변경될 수 있습니다.

(주)프리즘 www.prismlight.co.kr

경기도 부천시 부천로 198번길 36, 춘의테크노파크 101동 1307호

TEL: (032)652-2207 FAX: (032)652-4405

A/S 문의: (주)프리즘 또는 구입처 1588-2303



CLAYMOR3 TACE



User Manual

CLAYMORE 3Face mini


This portable light contains Li-Polymer batteries. Please follow the user manual before use. If any abnormality is found in the product, discontinue use and contact the dealer or a service center where the product was purchased. Any modifications of this product will void the warranty. Misuse of CLAYMORE products may cause user harm.

1. Caution

- ① Do not use near high temperatures such as fires or heating equipments. It may cause explosion and ignition.
- This product is water resistant. However, if left in the rain for a long time, it may cause explosion of the product gets soaked, please quickly wipe it off.
- 3 Do not store or use in vehicles exposed to direct sunlight, It may cause explosion and malfunction,
- Do not touch the light source directly as it may become very hot during use.
- (5) Do not use if the product exceeds the operating temperature range (-10 ° C to 40 °C).
- Do not look directly into the LED light source.


- ⑦ Please do not place in the reach of infants, It may cause swallowing of parts or injury.
 ⑥ Adult supervision is necessary when used by children. Misuse of head imp may cause injury or electric shock.
 ⑨ Do not insert any metal parts into the terminal block of the connector. It may cause heat, explosion or electric shock.
- O Do not disassemble or modify the product.
- (f) Do not touch the connector with wet hands. There is a danger of electric shock.
- ② After use, be sure to turn off the power. If not, it may cause leakage.
- When adjusting the angle, please do not bend with force. It may cause damage to the product.
- Dropping or impacting the product can cause damage to the inside of the product, resulting in unexpected failures in normal use. Be careful not to apply impact to the body.


2. Components




3. Operation

LED Light






When light is ON, press and hold button to increase brightness, Repeat to decrease brightness. *Light will blink once when Maximum and Minimum brightness is reached,





When light is on, press 3 button shortly to adjust the light color in three steps: Warm -> Bright -> Cool.

War	m LED light with low color temperature, warm light feels like ordinary gas lantern
Brig	nt LED light with a neutral color of daylight and comfortable feeling
Coo	LED light with high color temperature, cool light feels like ordinary fluorescent light



When light is OFF, hold @button for over 2 seconds to access SOS signal.

Power Bank Function



When a device is connected to the light it will automatically start charging. (On status : Battery indicator turns on)

Power bank cannot be used while charging the light.

Charging



- 1) Open rubber cover on the side and connect USB-C type cable to charge lantern.
- 2) When the product is charging, the battery indicator flickers. If the light is not flicking and all the lights are on, it indicates that the battery has been fully charged.

_		\rightarrow
	@® <u>;;</u> ;	

В	attery Level Indicator		
	" 000	0~25%	
	0.0	25~50%	Flickers
		50~75%	1 Heller 5
	111¥	75~99%	
	1111	Fully Charged	Stop

* This light contains memory function that returns to the last setting when turn off and on.

4. Instructions

This product is compatable with a strap and carabiner.

Mhen using a carabiner, be sure to insert it into the lower hole of the strap, (Prevent product fall in case of emergency)



* To mount on camera tripod: Turn the fixing screw on the camera tripod into the socket and fix it. It can be used with all1/4 inch screw accessories.



5. Specifications

CLAYMORE 3Face mini
CLF-500(LG/DG/MG)
Warm: 3000K, Bright: 4200K, Cool: 6500K (±15%)
40~800 Lm
6hr 30min ~ 60hr
78×102.5×19.7mm
159g
Li-Polymer 3.7V 5,000mAh(18.50Wh)
2hr 40min
USB 5V 2A
5V 2A
MADE IN KOREA

6. Contents







(USB Type-C)





⚠ Caution for long-term storage

- * If the battery is completely drained, the battery indicator might not flash.

 If this happens, plug the USB cable back in or press the button to turn the battery indicator on again.
- * For long-term storage, fully recharge the battery. (Repeat every six months) * Please keep in mind that if stored below -10°C the battery life may be affected.
- * Please keep in a dry place without moisture.

Warranty

Item	CLAYMORE 3Face mini
Model No.	CLF-500(LG/DG/MG)
Seller	
Date of Purchase	

- 1. Thank you for purchasing CLAYMORE series of Prism Co., Ltd.
- 2. This product has passed strict quality control tests. If the product is not functioning properly, please contact an authorized service center listed below.

1) Failure of the product under normal operating conditions during the warranty period will be repaired by Prism or authorized service center on free of charge. Some shipping or handling charges may be involved.

2)Warranty period: 1 year.

Charged Service

- 1) Damage caused when the warranty period is over.
- 2) Damage caused due to the user's mishandling, abuse, or improper operation.
- 3) Damage caused by arbitrary or personal repair or disassemble in unauthorized service center
- 4) Damage from input electricity or cable defect.
- 5) Damage caused by natural disaster.

CLAYMOR3

Prism Co., Ltd.

101-1501, Chunui-Technopark, Bucheon-ro 198 Road, 36, Bucheon-si, Gyeonggi-do, Korea www.claymorelight.com www.prismlight.co.kr info@prismlight.co.kr